

Am Jägersberg 5-7  
24161 Altenholz  
Germany

phone: + 49 - 4 31 - 3 69 60 - 0  
fax: + 49 - 4 31 - 3 69 60 21  
mail: info@hydrobios.de /  
sales@hydrobios.de  
web: www.hydrobios.de

## Ring-Trawl-Net

### 438 700 Ring-Trawl-Net

1. Bridle with thimble and shackle
2. Net ring of stainless steel tubing 1 metre diameter, with Nylon webbing and zip fastener
3. Net Part\*) consisting of:
  - a) NetPart with zipfastener, cylindrical, diameter 1 metre, length 1 metre, of synthetic material, mesh 500micron
  - b) Net Part, conical, upper diameter 1 metre, lower diameter 11 cm, length 3 metres, of synthetic material, mesh 500 micron
4. Plastic Net Bucket, consisting of:
  - a) Fixing Ring with overcentre fasteners for attaching to the end of a net
  - b) PVC-Net Bucket with side window, covered with sieve gauze

#### Accessories:

- 438 416** V-Fin Depressor with steel rope and shackle, weight 22 kg
- 438 110** Digital Flow Meter for counting the amount of water passing through the net

#### Spare Parts:

- 438 702** Spare Net Part\*) of synthetic material as discribed under point 3.
- 438 955** Spare Plastic Net Bucket, consisting of:
  - a) Fixing Ring with overcentre fasteners for attaching to the end of a net
  - b) PVC-Net Bucket with side window, covered with sieve gauze (as per choice between 100 and 500 micron mesh)

