



HYDRO-BIOS

Smart Sampling

Datasheet Center mount 1.7 + 2.5 l (436 380)



Centered Mounting Rack for samplers 1.7 + 2.5 l

Helpful tool to keep oceanographic water samplers in an upright position

Instead of adding heavy bottom weights the Centered Mounting Rack can be used to keep Plastic Water Samplers 1.7 litre or Free Flow Water Samplers 2.5 litres in a vertical position in case they are used as single instruments. This stainless steel tool is connected to the end eye of the wire and transmits the release impulse of the messenger to the sampler.

TECHNICAL DETAILS

weight on air	1.3 kg
materials	stainless steel
product ID	436 380

CHARACTERISTICS

- made from stainless steel