

airmoMEDOR®

ppt and ppt (M53)

Online analysis and monitoring of odorous sulfur compounds



Model: M53022 (rack version)

Environment:

- Monitoring of urban and non-urban pollution
- Monitoring of industrial nuisance
- Deodorization process
- Fugitive emission

Targeted compounds:

- Standard version: MM / EM / DMS / DMDS / DES
- Upon request: IPM / TBM / NPM / MES / 2BM / IBM / NBM
- With loop option: H₂S / SO₂ in ppb

Main markets:

- WWTP / Refineries / Petrochemicals / Gas process sites
- Ambiant / Industrial air monitoring
- Odor impact management
- Impurity in pure gas (CO₂ / CH₄ / H₂)

Standards:

- ISO 19739:2004, DIN 51855/7
- ASTM D 7493-22 & D7165-22

Certifications:

- GOST, ATEX, IECEx, CSA, CSA international



SCAN or CLICK ME



Chromatotec® is specialized in VOC, Sulfur and permanent gases analysis at trace and ultra-trace levels (% , ppm, ppb, ppt).
Please visit our website for more details.

* With Loop option

H₂S*

SO₂*

sulfides

Odor Index

DMS

DMDS

Mercaptans

Me-SH

Et-SH



Description:

The airmoMEDOR® is an automatic gas chromatograph (autoGC) for the analysis and monitoring of trace amounts of Methyl-Mercaptan, Ethyl-Mercaptan, Di-Methyl-Sulfide, Di-Methyl-Di-Sulfide and Di-Ethyl-Sulfide by electrochemical wet cell detection (MEDOR® technology).

Principle:

- Automatic sampling and concentration using an absorbant trap.
- Desorption from the trap and injection into a metallic capillary column.
- Isothermal gas chromatograph.
- The detection of all compounds eluting from the column is performed by an Electrochemical wet cell Detector which is Sulfur Specific Detector (SSD). This detector is using MEDOR technology.
- Signal provided by reaction between the wet cell electrolyte and the sulfur compounds.

Key points:

- Automatic calibration/validation of the data, with embedded permeation tube at ppb or ppt level on a daily basis in standard
- Continuous monitoring with automatic online sampling
- Analytical performances:
 - Specific, linear and very sensitive to sulfur compounds
 - Results validation by automatic standard injection
 - Long term stability using detector installed in reservoir
- Extremely low maintenance
 - Very long life time detector with electrolyte, up to 10 years
 - Low gas consumption, can be reduced in option
 - More than 10 years data storage
 - No cylinders required thanks to internal calibration tube and gas generators
- Automatic control with process device
- Intelligent system with tunable and interactive alarm levels
- Powerful VISTACHROM Chromatotec® software:
 - Remote monitoring & injection control
 - Full traceability with on board archiving of results and chromatograms
 - QC Set up and control of threshold alarms
 - Data export by MODBUS / 4-20 mA / 0-10 V
 - Time stamp results

Options:

- Multiple stream selector (up to 48 streams with one analyzer)
- Modeling software with weather station for live odor/chemical impact (XXXDISP)
- Explosion proof version Exp for ATEX, IECEx zone 1 and 2 and also for CSA C1D2
- Calculation modules (Average / Statistics / Odor unit OU e/m3 and more)
- Automatic data transfer through: Module for 4 outputs 4-20mA / Modbus RTU or TCP IP / MGS1
- **Nitrogen** or air generator
- 24 V DC power supply
- Electric selection valve to reduce air consumption
- Wall mounted box XXX934

Technical Specifications:

Sulfur compounds analysis: 5 compounds

- In standard: MM, EM, DMS, DMDS and DES
- With loop option: H2S and SO2 in ppb range
- In option: IPM, TBM, NPM, MES, 2BM, IBM and NBM
Other compounds on request

Detection limits:

- DES and DMS < 150 ppt (0.15 ppb)
- DMDS, MM and EM < 50 ppt (0.05 ppb)
- H2S and SO2 option < 5 ppb

Standard Detection Range:

- 0 to 100 ppb
- Other range on demand
- Calculation: Odor Index, Total Sulfur, Total mercaptans

Relative Standard Deviation:

- RSD < 3 % on concentration over 48H
- RSD < 0.5% on retention time over 48H

Cycle Time for the following different analyses:

• MM, EM, DMS, DMDS, DES	900s
• With H2S and SO2 option	2400s
• With IPM, TBM, NPM, 2BM, IBM, NBM and MES option	1800s

Supervisor:

- Embedded computer Windows® based with LCD display
- 128 GB of Hardware storage on SSD memory

Linearity:

- > 0.995 for all compounds

Communication:

- Ethernet, remote control

Gas supply:

- Carrier: Dry air or N2 (3 bars): ≤ 4 ml / min.
- CALIB: in continuous ~ 50 ml / min.
- CALIB during validation ~ 250ml/min
- Pneumatic valve 90ml/commutation

Power supply:

- Main: 230V 60Hz or 115V / 50Hz
- In case of power loss, the instrument will restart automatically

Electrical consumption:

- 150 VA

Dimensions and weights:

- Rack: 19" (5U)
- Height: 222 mm
- Width: 482mm
- Depth: 660 mm
- Net weight: 22 Kg

[CLICK HERE FOR ADDITIONAL DIMENSIONS DETAILS](#)

To order:

airmoMEDOR ppt - without computer - with peltier, dryer and CALIB
airmoMEDOR ppt - computer included - with peltier, dryer and CALIB

Model:
M53000 Trap

M53022 Trap

Chromatotec® is continuously improving its products, therefore these specifications are subject to change without notice

To contact us: sales@chromatotec.com

NORTH AMERICA
Houston - USA

EUROPE
Bordeaux- FRANCE

ASIA
Beijing - CHINA